GoXtreme® ACTION CAMS

RIDE THE ELEMENTS

GoXtreme® WiFi View

FULL HD ACTION CAM

1080p (1920x1080) 30fps VIDEO | WIFI FUNCTION

2.0"/5cm DISPLAY | 120° WIDE ANGLE

WATERPROOF CASE UP TO 45m | REMOTE CONTROL

GoXtreme®

WiFi View

Display	2.0"/5cm
Waterproof case	Up to 45m waterproof
Image sensor	5.0 Mega Pixels CMOS Sensor
Still Image Resolution	10MP (3648x2736), 8MP (3264x2448) by interpolation, 5MP (2592x1944), 3M (2048x1536)
Image File Format	JPG
Video Resolution	1080P (1920x1080P) Pixels 30fps, 720P (1280x720P) Pixels 60fps / 30fps
Video File Format	MOV, H.264 compression
Video with sound	Yes
Remote control	To make movies/pictures and to power off the camera (no power on function!)
Memory	Micro SD card support up to 32GB minimum Class 6 (not included)
Microphone	Build-in
Aperture	F3.1 f=2.9mm
Shutter Control	Electronic
Focus	Fixed wide angle 120°
EV Compensation	Auto
Sensitivity	Auto
White Balance	Auto
Scenes	Auto
OSD Language	English
Playback	YES (Connect the USB/HDMI)
PC Interface	USB 2.0
HDMI Port	YES
Power Source	1200mAh lithium battery (exchangable)
Dimensions	59 x 44 x 25.5mm, 70g
Working Temperature	-5 °C to +40 °C
System requirements	
for mass storage function:	Microsoft Window 2000, XP, Vista, Win7, Win 8, Mac OS X 10.0.0 or above
for pc cam function:	Microsoft Window XP (SP3), Vista, Win7, Win 8, Mac OS X 10.8.0 or above

ACCESSORIES INCLUDED

Waterproof case	Remote control
Protection shield	Car charger
Surfboard mount	Battery
Bike mount	USB cable
Helmet mount with band and sticker base	Manual CD

WIFI CONNECTION IN 3 STEPS

1. Download the app from the App Store or Google Play
2. Connect the cam to iOS or Android device via WiFi
3. Control'n Play the cam by your phone or tablet or transfer images or videos to your device and share them with your friends

easypix® LIFESTYLE ELECTRONICS

Technical changes and mistakes reserved!